



## Using The USB Notebook Adapter Quick Start Guide

This adapter will add a Stereo LINE INPUT to any PC running Windows or Mac. There's nothing special that you need to do.

1. Plug the RCA Plugs at one end of the USB Adapter into the RCA Jacks marked AMP/Soundcard out on the Mixer. You may ignore the extra 3.5mm plug for now.
2. Plug the USB Plug at the other end of the Adapter into any of your notebook's USB Jacks. Do NOT plug it into a USB hub. Plug it directly into a USB Jack. Your computer should signal to you that it recognizes the Adapter. After it does, launch the DAK Wave Editor. Start your music source and hit the record button.

You should see waves. You can adjust the volume as required.

**You may not hear the sound** through your computer speakers as you record as the adapter is an external sound card and external sound cards don't always provide sound during recording

**Or, to hear sound while you record**, in the package, you'll see a special 3.5mm to 1/4" stereo adapter. Plug it into the front Headphone Jack of the Mixer and plug in a pair of earbuds or computer speakers so you can monitor the sound of your music.

**After you have recorded**, your PC will play sound normally to the speakers in or connected to your laptop as you play back what you've recorded.

Contact us at [CS@DAK.com](mailto:CS@DAK.com) if you have any questions.